



Advanced Analytical Solutions *Your laboratory evaluation solution.*



www.AdvancedQA.com
Info@AdvancedQA.com

6325 Emerson Avenue
Parkersburg, WV 26104

(800) 283-4844
(304) 485-6325

SAMPLE PREPARATION INSTRUCTIONS
BENCHMARK PERFORMANCE AUDIT
WASTE WATER (WP) SERIES

Please follow these guidelines for preparing your sample. Proper sample preparation along with appropriate QC methods will allow the greatest chance for assay success. All samples should be mixed well before use and stored at 4°C upon dilution.

pH:

This sample is whole volume. It is therefore ready to use upon arrival. Analyze it the same as any other sample.